

Presentation Function

Share content from a laptop or other device.

1. Connect the VGA cable to the VGA output on your laptop. Use an adapter if necessary (**DVI to VGA, Mini-DVI to VGA or Mini DisplayPort to VGA**).



2. Adjust the Display Settings on your laptop by going to **Start—Control Panel—Display**. You will need to set your laptop to a resolution of 1024 x 640 or lower.
*NOTE: Mac users go to **System Preferences—Display—Detect Display***
3. Press the Presentation button. If resolution isn't correct you will see "PC Not Connected." If *nothing* happens, make sure you are pointing the remote at the camera.



4. You should now see the image from your laptop on the monitor.
5. If your presentation involves sound, you must also plug in the audio component of the VGA into your laptop.

Need help?

Contact your Library System's IT Department

6. Press Presentation to toggle back and forth between the Main Camera and Presentation.
7. Remember to turn Presentation off when you are done using it.

Need help?

Contact your Library System's IT Department